

Unit switchs and connections.

Off/On switch.

 Power up the unit. For optimal performance, always ensure that the unit is turned off before connecting or disconnecting the camera.

Charge port.

 To ensure optimal performance, please make it a habit to plug in the unit for charging after every use.

Camera port.

• Connecting or disconnecting the camera, ensure the unit is off.

HDMI port.

• To play directly to an external monitor using an HDMI cable.


USB port.


 Connect an external drive to save all files from the camera unit.



Connecting the Camera

- To achieve optimal performance, carefully inspect the camera connection and cable to ensure the holes are perfectly aligned.
- For optimal results, gently guide the two parts together; they should fit smoothly and effortlessly.
- Firmly tighten the cable section to guarantee a reliable and watertight connection you can trust.
- Ensuring a secure connection is crucial, as any water intrusion can lead to significant damage to the unit.





Maintenance

- To ensure optimal performance and longevity, always rinse the pole and camera with fresh water after each use, keeping the camera cable connected during the process. This simple step will help protect your equipment from damage and enhance its durability.
- To ensure optimal performance and longevity, it's essential to disassemble all screws, bolts, and nuts monthly. Rinse them with fresh water to remove debris, then reassemble and apply a corrosion-resistant spray to all threads. This simple maintenance routine will protect your equipment and enhance its durability.

Front Screen

- Micro, Enhance your video recordings by attaching the supplied external microphone to enrich your audio with clear speech for informative content.
- Red Button, start recording.
- Green button, end recording.
- Blue button, screen snapshot.
- LED light, battery status.





Remote control

- On/Off, slide button
- Power button, Wake your controller from sleep mode.
- Touch pad, Enhance the functionality of the Marine Vision interface by optimizing the mouse cursor movement
- Keypad, The keypad is essential for efficiently inputting the information needed to create overlays and meet all your typing requirements.



Accessing the menu

- Start by powering up the unit.
- double-tap to access the log in via the touchpad.
- Then, tap OK to proceed.
- There's no need to enter a password; tap OK again.
- In the centre of the blue screen, double-tap the touchpad to bring up the Pop-up menu seamlessly.



Overlay, allows for written information to be displayed on the recording or snapshot

- In the pop-up menu, tap on the overlay
 - Tap on the following names to enter.
 - Ensure in DEVICES, COMPANY NAME and COMMENTS screens they have the check box unchecked by display when in these screens.
 - When exiting these screen tap apply to save and then menu to exit.

- The following will need to be repeated for every debrief.
 - Enter into Project name
 - Enter the Project name
 - YACHT NAME_BOOKING REF
 - Ensure Display is ticked
 - Tap on Apply to save
 - Tap on Menu to exit
 - Enter into Date/Time and ensure all is correct and Display is tick
 - To save tap on Apply
 - Menu to exit



Search

- Allows you to review snapshots and recordings.
 - Tapping on MODE allows you to select the recordings or Snapshots
 - Selecting the date will bring up all those recordings or snapshots on that date.
 - Tapping on the file name will start to play the recording or show the Snapshot.

Backup

- Allows you to back up your recordings and snapshots to a USB external storage device.
- Tapping on MODE allows you to select the recordings or Snapshots
- Selecting the date will bring up all those recordings or snapshots on that date.
- Tapping on the file name will select the file to backup onto your external storage device.
- Tapping on START will back up the connected device.





- 1. Please be cautious while walking with the pole to ensure your safety and the safety of others.
- 2. Stay aware of your surroundings to prevent collisions with people and equipment.
- 3. Protect the Marien vision system from any potential damage.
- 4. As you move with the pole, pay attention to the camera cable connected to the unit to avoid stressing the connections.
- 5. Always secure the central unit by using the strap around your neck for added safety.
- Rinse the pole and camera with fresh water after every use to maintain their condition.
- 7. Remember to gently wipe the screen with a soft cloth after each use to keep it clean and operational.